

备件清单

Code	Name	Spec No.
1.1.03.002.1023	Flash	S29GL064N90BF1040
1.1.03.002.1051	SDRAM	AS4C8M16S-6TCN
1.1.03.004.1016	Power IC	TD6821
1.1.03.004.1028	Power IC	BQ24133RGY
1.1.03.004.1043	Power IC	TD1583PR
1.1.12.003.1073	LCD	GXH12864-82
1.1.12002.1001	Battery	CR2032/006334
1.1.03.999.1012	IC	BQ32000DR
1.1.12.004.1045	Printer Head	ATP2SSP6RNEA
1.1.12.004.1002	Printer Head	PT486F-B
1.1.12.004.0001	Shaft	118-OPC1000-00
1.2.02.001.0001	Front Shell	100-OPC1000-00
1.2.02.001.0002	Rare Shell	101-OPC1000-00
1.2.02.004.0002	Carton Hand	105-OPC1000-00
1.2.02.004.0031	Lens	103-OPC1000-00-E08
1.2.03.001.0044	Silicon Key	106-OPC1000-00-E04
1.2.03.003.0011	Switch Plug	130-OPC1000-00
1.2.02.001.0010	AC Power Cable	H03vvHz-F(2X0.75mm)
1.2.12.001.1020	Battery	KPL464854-2S
1.2.12.003.0002	LCD	VTM88858001
1.1.12.007.1071K	Power Adaptor	NBS24J09250M2: SH01942
1.1.12.007.1019	Power Adaptor	P36-090250(pc1000)
1.2.02.004.0001	Carton Cover	104-OPC1000-00
1.3.02.001.0031	Power Cable	+SPT-2 18/2C
1.2.08.009.1005	Plug	SW-D4-001